

COVERAGE FOR YOUR TIER OF LIFE







24/7 ROADSIDE ASSISTANCE

RENTAL ASSISTANCE COVERAGE

ALPHA TIERED™





Florida License #6001600) depending on your state. Please







CHOOSE FROM FIVE LEVELS OF COVERAGE

ELECTRICAL: Alternator, starter motor, voltage regulator, horns, neutral safety switch, reverse indicator switch, turn signal switch, distributor, cruise control switches.

FUEL SYSTEM: Fuel pump, fuel injection pump, metal fuel delivery lines.

OPTIONAL COVERAGE

ENHANCED SEALS & GASKETS: An option that when applied covers seals and gaskets of covered parts on vehicles with up to 125,000 miles at the time of sale. Minor loss of fluid or seepage is not considered a mechanical breakdown and is not covered. This option is only available on powertrain plus.

EXTENDED COVERAGE

UP TO **263 PARTS** COVERED

ALL LIMITED POWERTRAIN AND POWERTRAIN PLUS PARTS PLUS THE FOLLOWING:

ENHANCED COOLING: Electric radiator fan motor, fan clutch, fan blade and coolant recovery retainer.

ENHANCED DRIVE AXLE: Axle shafts, propeller shafts, constant velocity joints, double offset joints and drive shaft center support bearings.

ENHANCED AIR CONDITIONING: Compressor seals, receiver drier, idler pulley, field coil, condenser, evaporator core, expansion valve, pressure cycling switch, accumulator, orifice tube, and inside ambient temperature sensor. The following parts are only covered if necessary for a covered repair: evacuation and recharge.

ENHANCED ELECTRICAL: Power window motors, power window regulators, starter motor solenoid, wiper motors, washer pumps, ignition igniter, ignition module, coil packs, power seat motors, manual seat adjustment mechanisms, crankshaft position sensor, headlamp switch, blower motor speed switch, ignition switch, ignition switch lock cylinder, knock sensor, and stop lamp switch.

TURBO OR SUPERCHARGER: All internally lubricated OEM parts of the turbo or supercharger. Turbo or supercharger case is only covered if damaged by an internally lubricated part of the turbo or supercharger.

STEERING: All internally lubricated parts of the steering rack and pinion gear. Steering box, steering pump, electric power steering motor, drag links, idler arm, internal tilt wheel mechanism, pitman arm, steering column shafts, couplings, and tie rod ends.

SEALS & GASKETS: Intake manifold gaskets. All other seals and gaskets are only covered if necessary for a covered repair. Minor loss of fluid or seepage is not

considered a mechanical breakdown and is not covered.

BRAKES: Master cylinder, wheel cylinders, power brake booster, proportioning valve, disc brake calipers.

SUSPENSION: Stabilizer, stabilizer bar links, sway bars, sway bar links, spindles. Leaf and coil springs are only covered if they are broken.

SUPREME COVERAGE

UP TO **389 PARTS** COVERED

ALL LIMITED POWERTRAIN, POWERTRAIN PLUS, AND EXTENDED COVERAGE PARTS PLUS THE FOLLOWING:

ABS: Electronic control module, hydraulic pump assembly, accumulator, pressure modulator valve, isolation dump valve, axle pick-up unit and reservoir.

MODULES: Body, transmission, ABS and climate control.

CRUISE CONTROL: Vehicle speed sensor and wheel speed (ABS) sensor.

ENHANCED SEALS & GASKETS: Seals and gaskets of covered parts on vehicles with up to 125,000 miles at the time of sale. Minor loss of fluid or seepage is not considered a mechanical breakdown and is not covered.

DELUXE COOLING: Radiator, heater core and heater control valve.

DELUXE ELECTRICAL: Power antenna motor, sunroof motor, heater blower motor, power door lock actuator, idle speed control motor and hand operated switches.

ENHANCED FUEL: Fuel pressure regulator, fuel injectors, fuel sending unit, fuel gauge and control valve, fuel tank.

ENHANCED SUSPENSION: Wheel bearings, hub assemblies, control arm shafts. Ball joints are only covered after 60 days and 2,000 miles from the date of purchase.

FULL COVERAGE



Includes the mechanical breakdown of all parts except for exclusions listed in the contract.

LIMITED **POWERTRAIN**

UP TO 130 PARTS

ENGINE: All Internally lubricated parts including: balance shaft bearing, balance shaft bushing, balance shaft, cam followers, oil pump housing, rocker bushings, cylinder barrels, eccentric shaft, camshaft and bearings, lifters, rocker arms, rocker shaft, timing gears, timing chain, pistons, piston rings and pins, connecting rods and bearings, crankshaft and main bearings, oil pump, pump gears and pickup screen, push rods, intake and exhaust valves, valve guides, valve springs, valve locks, valve retainers, valve seals, and valve seats. Harmonic balancer, exhaust manifolds, engine torque strut, engine mounts, intake manifold, and timing belt. The engine block, cylinder head, valve cover, timing cover and oil pan are only covered if damaged by an internally lubricated part of the engine.

TRANSMISSION AND TRANSFER CASE: All internally lubricated parts of the transmission, transaxle and transfer case including: bushings, main shaft washers, oil pump, output shaft, drive chain gears, drive chain, shift bushing, drum, planetaries, sun gear, shell, shafts, bearings, shift rails, forks and synchronizers. Flywheel, flexplate, torque converter, shift linkage, vacuum modulator, throttle position sensor, and transmission mounts. Transfer case, transmission and transaxle cases are only covered if damaged by an internally lubricated part of the transfer case, transmission or transaxle.

COOLING: Water pump and thermostat.

DRIVE AXLE: All internally lubricated parts of the differential (both front and rear) including: bearings, bushings, oil pump, ring and pinion, washers. Universal joints, and locking hubs.

POWERTRAIN PLUS

UP TO 153 PARTS

ALL LIMITED POWERTRAIN PARTS PLUS THE FOLLOWING:

AIR CONDITIONING: Compressor, compressor clutch and clutch bearing. The following parts are only covered if necessary for a covered repair: accumulator, receiver drier and orifice tube.